Secondary audio programming
INSTRUCTIONS

Secondary audio programming (SAP) is an alternate audio channel for television that can be broadcast through individual programs or through a television network. It is often used to provide audio tracks in languages other than English, like Spanish, or for Descriptive Video Service for the visually impaired. If no additional audio track is available, there will be no sound at all or it may be in English.

To find out if the program you would like to watch has SAP, look for "SAP" in the lower left corner of the television screen when the program is starting, or you may follow the instructions below:

ENTERTAINMENT PLAN

1. Press the MENU button on your remote control
2. Using the right arrow, scroll to "Settings"
3. Press the OK button
4. Using the right arrow, scroll to "Audio"
5. Using the down arrow, scroll to "Secondary Audio"
6. Press the OK button
7. Press the right arrow then the down arrow to "Use secondary audio if available"
8. Press the OK button
9. Press the left arrow, then the up arrow to "Save"
10. Press the OK button
11. Press the EXIT TO TV button to return to your program

Follow the steps above to return to English

PLEASE NOTE

Commercials that don't have SAP will have no sound or they may be in English. If you experience no sound during any program or commercial, please follow the steps above to return to English audio programming.

888.99.ARVIG | arvig.com

arvig
It's All Here

©Arvig 2018. This institution is an equal opportunity provider and employer.

Programación de audio secundario
INSTRUCCIONES

Programación de audio secundario (SAP en sus siglas Inglés) es un canal de audio alternativo para la televisión que puede ser transmitido a través de programas individuales o por medio de una red de televisión. A menudo se utiliza para proporcionar pistas de audio en idiomas distintos del Inglés como Español o Descriptivo Servicio de Video (DVS en sus siglas Inglés) para las personas con discapacidad visual. Si no hay ninguna pista de audio adicional disponible no habrá sonido o la pista será en Inglés.

Para descubrir si el programa que desea ver tiene SAP por favor busque para las letras "SAP" en la esquina inferior izquierda de la pantalla de televisión cuando el programa está comenzando. También puede seguir las instrucciones debajo:

ENTERTAINMENT PLAN

1. Empuje el botón MENU en su control remoto.
2. Usa la flecha hacia abajo para ir a "Setup".
3. Empuje el botón OK.
4. Usa la flecha derecha ir a "Audio".
5. Usa la flecha hacia abajo ir a "Secondary Audio" (Audio secundario).
6. Empuje el botón OK.
7. Empuje la flecha izquierda y entonces la flecha hacia abajo para "Use secondary audio if available" (Usa el audio secundario si disponible)
8. Empuje el botón OK.
9. Empuje la flecha izquierda y luego la flecha hacia arriba para ahorrar "SAVE".
10. Empuje el botón OK.
11. Empuje el botón "EXIT TO TV" para regresar a su programa.

Siga los pasos anteriores para regresar a Inglés.

NOTAS

Los anuncios que no tienen SAP no tienen sonido o el sonido va a estar en Inglés. Si experimenta ningún sonido durante cualquier programa o anuncio por favor, siga los pasos anteriores para volver a la programación de audio Inglés.