

INTERNET DSL Modem & Router

Installation Guide

*Don't forget to contact us
to complete your upgrade!*



phone cord
(color may vary)

Components required:



Modem



ethernet cable
(color may vary)



power cord

Username _____

Password _____

You received these from Arvig when you upgraded your internet service.

Step 1: Remove the new modem from the box and place it flat on a desk or table—do not block vents.

Step 2: Unplug the phone cord from the old modem (DSL or LINE port), and plug it into the A/VDSL port on the new modem.



Step 3: Unplug the ethernet cable for your computer or router from the old modem, and plug it into the yellow Ethernet port on the new modem.



Step 4: Use the provided power cord to connect the Power socket to an appropriate power source. Confirm the DSL light on the top panel is solid (about 2-5 minutes). Then proceed with step 5.



Components required:



— Wireless
4-port
Gateway

— equipment
stand



ethernet cable
(color may vary)



Step 5: Remove the new router from the box and place it flat on a desk or table, or in the included stand for vertical installation—do not block vents.

Step 6: Now unplug the ethernet cable from the old router or your computer, and plug it into the ETH-WAN port on the new router.

Step 7: If applicable, unplug the ethernet cables of your connected devices from the old modem/router, and plug them into ETHERNET ports 1-4 on the new router.

Step 8: If using a desktop computer, use the provided ethernet cable and plug one end into the ethernet port on the computer and the other end into ETHERNET ports 1-4 on the new router.

Step 9: Use the provided power cord to connect the POWER socket to an appropriate power source.

Step 10: To complete the setup process, call Arvig Technical Support at 877.290.0560 for assistance. We're also available via online chat at arvig.net.

Verify your new internet speed by testing it at speedtest.arvig.com.



877.290.0560

arvig.net/selfinstall



arvig®
It's All Here